




Life Changing Sensory Solutions For All

snoezelen®

INSTRUCTION MANUAL

EN-US



**SNOEZELEN® HIP HOP ACTIVITY BOX™
WALL PANEL & FLOOR PAD**

24514

01.

CONTENTS

CONTENTS

ABOUT THE PRODUCT	4
Product Description.....	5
User Benefits	5
Product Compatibility	5
TECHNICAL SPECIFICATION	6
Included Parts.....	7
Technical Specification	7
SAFETY AND CARE.....	8
Product Safety and Care Instructions	9
ASSEMBLY & INSTALLATION GUIDE	12
Product Assembly Guide/Installation.....	13
Troubleshooting.....	14
USER GUIDE	16
User Guide	17
FEATURES	20
NOTES.....	22

02.

ABOUT THE PRODUCT

Product Description

Immerse yourself in a world of interactive fun and learning with the soft play floor pad. This versatile pad allows you to play games, create music, and trigger mesmerizing shows of light and colour, all from a single, engaging platform. The panel is brimming with a variety of games, musical compositions, and sound effects, offering endless hours of entertainment and educational opportunities.

Designed to encourage movement, creativity, and composition, the floor pad helps develop essential skills such as listening, meaningful activity, and an understanding of cause and effect. Whether you're dancing to the rhythm, composing your own tunes, or exploring the vibrant light displays, this innovative product fosters a dynamic and stimulating environment for users of all ages.

User Benefits

This product is designed to encourage interaction, visual tracking, hand-eye coordination, and an understanding of cause and effect. By engaging with the product, users are prompted to interact with their environment and with others, fostering social connections and collaborative play. The vibrant visuals and dynamic movements help develop visual tracking skills, as users follow the motion and changes in their surroundings.

Hand-eye coordination is enhanced through activities that require precise movements and timing, helping users to improve their motor skills and spatial awareness. Additionally, the product's interactive features demonstrate the principles of cause and effect, allowing users to see the direct results of their actions. This understanding is crucial for cognitive development, as it helps users make connections between their behaviours and the outcomes they produce.

Overall, this product provides a comprehensive and engaging way to develop essential skills while having fun.

Product Compatibility


20848 / 21098 Sensory Magic® 2 Panel / Sensory Magic® 2 Portable
23717 / 23725 Sensory Magic® 3 Compact / Sensory Magic® Compact Plus
21098 Sensory Magic Portable®
19847 Deluxe 8 Colour Wirefree Controller
21006 8 Colour Wirefree Switch
18870 Talking Cube
20402 Mini Talking Cube
24515 Colour Command Centre™
21918 Wi-Fi Override Transmitter
21728 Wi-Fi App Control Box
22867 Wireless Colour Controller Cushion wall mat

TECHNICAL SPECIFICATION


03.

Included Parts

- 1x Hip Hop Activity Box™ Wall Panel
- 1x Hip Hop Activity Box™ Floor Pad
- 2x Wall Mounting Bracket
- 4x M4 Screws
- 1x UK Mains Lead
- 1x US Mains Lead
- 1x EU Mains Lead
- 1x Mounting Template (for use during installation)



Panel




Floor Pad

Technical Specification


Panel

Weight: 12kg
27lbs
Dimensions: 115H x 67W x 10cm
26-3/8W x 4D x 45-1/4H in
Input: 100-240V 50/60Hz
Output: 5V DC 10A
Material: ABS (Phthalate-Free)



Floor Pad

Weight: 12kg
27lbs
Dimensions: 145H x 72.5W x 15 cm
57H x 28-1/2W x 6 in
Input: 100-240V 50/60Hz
Output: 5V DC 10A
Material: ABS (Phthalate-Free)



04.

SAFETY AND CARE

Product Safety and Care Instructions

Operation

- The Panel must always be used under supervision.
- Do not strike the panel. The panel is built robustly, but intentional misuse will shorten it's lifespan.
- Do not open, dismantle, or attempt to repair the panel yourself. This this may cause injury and will invalidate the warranty.
- Disconnect any cables when installing or moving the product. Pulling of the cables can cause premature wear or damage to the product and/or accessories.
- If the product generates abnormal sounds, a burning smell, or smoke, disconnect immediately and contact Rompa® customer services.
- Do not press and hold the panel push buttons for durations of longer than a minute. Over time this may reduce the life expectancy of the product.

Care and maintenance

To prolong its product life, please read the following instructions when installing and operating this panel:

- When installing please ensure to keep the layer of protective film on the screen until the whole panel is fully mounted and is ready for use.
- Ensure no sharp tools or objects are near to the screen.
- Rompa® recommends using a soft microfibre cloth for cleaning and dusting. Doing so optimises the finish and will prevent scratches onto the screen.
- Slightl dampening of the cloth, or use of isopropyl alcohol is recommended for more stubborn stains. Ensure the panel does not become wet.
- Particular care should be taken around apertures in the chassis and any electronics (touch screen, power button, illuminated push buttons, external switch jacks and microphone input jack).
- Avoid food or drinks near this panel.
- Do not attempt to physically damage the product including the electronics, screen and buttons.
- Ensure loose wires are out of sight.
- At the end of the product's life, please dispose of it ethically. Recycle wherever local facilities exist.

ASSEMBLY & INSTALLATION GUIDE

05.


Installing Wall Bracket & Panel

Ensure that, after installation, the mains plug and/or power switch for the panel is easily accessible to facilitate removal of power. Due to the size of the product, it is recommended that two people install the product.


Recommended tools

- Drill
- Spirit level
- Pencil
- Tape measure
- Appropriate fixings (e.g., screws, wall plugs, etc.)


Panel Overview (Front)




Panel Overview (Rear)




Mounting Dimensions mm [in]





1. Prepare a soft, padded, level surface, such as a quilt or rug. Carefully lay the panel face down.
2. The wall brackets are secured from the factory to prevent damage during transit. Locate and remove the 4x M4 screws on the sides of the panel (as per the arrows above) securing the 2x brackets in place. Place the screws in a safe place, as they will be required later.
3. Remove both brackets from the panel by sliding them down and lifting them out. Place the brackets safely to one side, as they will be required later.



4. Unfold the paper mounting template. This 1-1 scale drawing is an accurate mounting guide. Position and affix it to the wall in the desired location, ensuring it is completely flat and level. If you use a tape, such as masking / painter's tape, please ensure it will not damage your wall. Once in place, this guide shows you where you will need to mount the brackets relative to the unit, and where you will need to drill into the wall. You can use it to mark the wall, or you can drill directly through the template. Once you have completed this task, we recommend that you carefully refold the paper template and retain it for future reference.

If you don't wish to use the paper template, the graphic on the previous page shows the exact measurements you will need.

5. Secure both brackets to the wall according to the the marks on the paper template. Please note that fasteners are not supplied, and must be purchased separately. Please ensure the correct fasteners are used dependant on the construction of the wall. Due to the wide range of wall construction types, we recommend consulting a skilled professional to identify the best type of fixing for each installation.
6. Clean the wall and brackets of any dust and debris which may have been created during mounting. They will be inaccessible once you move beyond this step.
7. With the panel still laying face down, plug in the power cable and any other controller cables, route them through the power cable clamp and power cable cut out. Tighten up the cable clamp to secure the cables.
8. With the help of an assistant, carefully lift the panel and locate it on the wall brackets. To do this, have the panel slightly higher than its final resting position. Ensure the trailing cables remain clear of any obstruction during the lift. When you feel the panel has located into the bracket, gradually lower the panel into position. Once correctly in position, the panel will hang from the brackets under its own weight. It will sit flush against the wall, and the brackets will now be fully concealed. Check the cables are not caught up behind the panel.
9. Reinstall the 4x M4 screws into the mounting bracket holes on the sides of the unit, to prevent the panel being lifted off the brackets. It will now be firmly in place.
10. Plan your cable routing so as not to cause a hazard. It is advisable to conceal any cable to protect it from damage, eg. using conduit. Consult a qualified electrician if you are unsure of best practice.
11. Your panel is now ready to be connected and switched on.

Troubleshooting

No Sound or Low Volume

- Ensure volume is on and turned up to a sufficient level via the touch screen.
- To do this press use the arrows on the touch screen to navigate to the sound menu, select the '+' icon to increase the volume.
- The speaker icon is turned all the way up when the icon looks the same as it is seen below:



If this still does improve there being no sound or the sound not being loud enough, try the following steps:

- Turn the panel off and wait 10 seconds.
- Turn the panel back on.


This will reset the panel settings and revert the sound to volume 2 and Sound Effects set to on.

Frozen or Unresponsive

- Turn the panel off and wait 10 seconds.
- Turn the panel back on. This will reset the panel and revert the 1st mode shown on Touch Screen.

Push Button(s) Unresponsive

- Ensure panel buttons are not locked via the touch screen.
- To do this press the arrows on the touch screen until you are on the panel lock menu:




- Pressing the red lock button will lock and unlock the illuminated push buttons.
- When locked (as seen in the image above) the push buttons will dim and be unresponsive.

External Switch Unresponsive

- Ensure the switch inlet is clear of any dust or debris.
- Ensure the switch is fully inserted into the inlet.
- Ensure panel buttons are not locked via the touch screen.
- Turn the panel off and wait 10 seconds.
- Turn the panel back on. This will reset the panel settings and revert the panel buttons to unlock.

No Power

- Ensure the mains power is disconnected from the panel before then checking the IEC power cable (kettle lead) is connected into the bottom of the panel and is fully inserted into the panel.
- Then turn the mains back on.
- If the IEC cable is securely in place and there is still no power to the panel, then ensure that the plugs fuse has not blown and replace if required.
- The IEC power cable plugs into the panel as illustrated by the line with the Power In (and on selected products, Floor Pad In) text next to it:



If troubleshooting does not solve the issue please contact Rompa® Customer Services
+44 (0) 1246 211 777

06.

USER GUIDE

User Guide

Operation

Modes

The mode dictates how the panel behaves. The Hip Hop Activity Box™ has 6 modes which can be selected via the touch screen and an additional mode when a microphone is plugged into the ¼"/6.35mm microphone input:

Mode 1:

One Light/ One Note When a colour on the floor pad is selected the entire panel screen will light up the same colour and play an associated sound effect. The sound effect played is determined by the theme selected via the illuminated push button and colour on the floor pad. The user must wait until the sound effect finishes before they can trigger a new colour/ sound effect. To trigger the same colour and sound effect twice in a row the user must step off and back onto the floor pad

Mode 2:

Multiple Lights/ Multiple Notes When a colour on the floor pad is selected the corresponding square on the panel screen will light up the same colour and play an associated sound effect. The sound effect played is determined by the theme selected via the illuminated push button and colour on the floor pad. The user does not have to wait until the sound effect finishes before they can trigger a new colour/ sound effect. To trigger the same colour and sound effect twice in a row the user must step off and back onto the floor pad.

Mode 3:

Lights Out A game is started by pressing any button on the floor pad which will trigger a 3 second auditory countdown. The panel will illuminate a random number of squares (dependant on difficulty selected) and the user has to press the corresponding colours on the floor pad to extinguish the lights and score points. The user must score as many points as possible before the time runs out. An auditory and visual reward is played when the game ends and the score is displayed via the touch screen. To trigger the same colour twice in a row the user must step off and back onto the floor pad.

Mode 4:

Colour Memory A game is started by pressing any button on the floor pad which will trigger a 3 second auditory countdown. The panel will illuminate a random square which will then extinguish. The user has to press the corresponding colours on the floor pad to score a point. The panel will then display the same colour again but add a second colour to the sequence. This will continue until user incorrectly repeats the sequence of lights shown by the panel. An auditory and visual reward is played when the game ends and the score is displayed via the touch screen. To trigger the same colour twice in a row the user must step off and back onto the floor pad.

Mode 5:

Song and Lights A song and light pattern is linked to each colour of the floor pad. Selecting a colour on the floor pad will trigger the pattern and song to start playing. At any time the user can select a different song and pattern by stepping on another colour. To trigger the same colour twice in a row and start the song from the beginning the user must step off and back onto the floor pad. The 'Theme' illuminated push button is inactive in this mode.

Mode 6:

Create a Song The user must first select a song by stepping on a colour of the floor pad (a different song is associated with each colour). This will trigger a 3 second auditory countdown. The panel will then illuminate a random number of squares. The user must select the corresponding colour on the floor pad to extinguish the light and play the first note or segment of the song (depending on difficulty will determine the number of steps required to finish the song). The user must continue to extinguish the lights to finish the song. An auditory and visual reward is played when the song is complete. To trigger the same colour twice in a row and start the song from the beginning the user must step off and back onto the floor pad. 11 The 'Theme' illuminated push button is inactive in this mode.

Microphone Mode:

This mode cannot be accessed via the touch screen. To access this mode plug a microphone into the ¼"/6.35mm microphone input. The panel will automatically change to microphone mode once a microphone has been detected. The mode and brightness of the panel cannot be adjusted via the touchscreen whilst a microphone is plugged in. Use the floor pad to change the colour of the panel. The brightness of the panel is then controlled by the volume of sounds made. The louder the sound the brighter the panel will go.

All Modes: Passive Colour When the panel has been inactive for more than 5 minutes the panel will fade through colours creating a relaxing passive effect.

Touch Screen:

The touch screen is intended for the supervisor of the session not the primary user of the panel. The touch screen allows you to control in detail how the panel behaves as well as view statistics of panel usage. Upon booting the panel up it will revert to its default settings:

Mode 1: Interactive

Volume: 2

Touch Screen Brightness: 100%

Panel Brightness: 100%

Sound Effects: On

Wi-Fi: On

Lock: Off



Mode 5:

Press the light blue mode button to cycle through the modes of the panel. Press the red forward or back buttons to cycle through the other menu options.


Difficulty:

Pressing at the face will give you different levels of difficulty in that mode. The level of difficulties are:

Green = Easy

Orange = Intermediate

Red = Advanced



Media*

Pressing the 'play/ pause' button to play or pause music. Press the 'skip forward' to play the next track or 'skip back' to play the previous. Press the red forward or back buttons to cycle through the other menu options. *An SD Card with compatible mp3 files must be inserted to use the media functionality.




Volume

Pressing the '+' will increase the volume and pressing '-' will reduce the volume. Press the red forward or back buttons to cycle through the other menu options.



Sound Effects

Pressing the light green sound effect button will cycle the sound effects on or off. Sound effect refers to the sounds made when the user activates the illuminated push buttons. Press the red forward or back buttons to cycle through the other menu options.




Touch Screen Brightness

Pressing the yellow touch screen brightness button will cycle the touch screen through 6 levels of brightness. Press the red forward or back buttons to cycle through the other menu options.




Panel Brightness

Pressing the light green sound effect button will cycle the sound effects on or off. Sound effect refers to the sounds made when the user activates the illuminated push buttons. Press the red forward or back buttons to cycle through the other menu options.



Lock

Pressing the red lock button will lock and unlock the illuminated push buttons. When locked the push buttons will dim and be unresponsive. Press the red forward or back buttons to cycle through the other menu options.



Wireless Product Connection

Pressing the purple wireless button will cycle the panel Wireless on or off. With wireless turned on the panel will respond to other Rompa® compatible wireless products. With wireless turned off it will ignore Rompa® compatible wireless products. Press the red forward or back buttons to cycle through the other menu options.



Stats

Pressing the blue stats will open the stats screen. From the stats screen you can see real time the amount of button presses have been made on the panel and the duration the panel has been used for.

To return to the main menu press the red backward button Press the red forward or back buttons to cycle through the other menu options.



Illuminated Push Buttons

The Hip Hop Activity Box™ has 1 illuminated push button so the user can control select the theme of sound effects associated with the panel. When pressed the button will flash and a unique sound effect will be triggered.

Sound effects can be 15 turned off via the touch screen. Illuminated buttons can also be locked via the touch screen if required.

The brightness of the illuminated buttons is reduced and the buttons are unresponsive when locked.

Theme

The panel has 7 themes which can be selected via the 'Theme' illuminated push button or an external switch plugged into the 'Theme' 1/4"6.35mm input jack.


Theme dictates the sound effects which are triggered when interacting with the floor pad.



External Switches


The panel has 1 external switch input each located underneath their associated illuminated push button.

To connect the external switch simply plug into the 1/4"6.35mm jack and remove when finished (external switches without a 1/4"6.35mm jack may need an adapter fitting).



Microphone Input

The panel has 1 microphone input. To use a microphone with the panel simply plug a microphone into the ¼"/6.35mm jack located in the bottom right of the 16 panel. When the microphone is inserted the panel will automatically detect its presence and turn to 'Microphone Mode'. The panel also acts as a karaoke and sounds spoken through the microphone can be heard through the integrated speaker. Simply remove the microphone from the panel when finished and the panel will automatically revert back to its previous mode.



Themes

The panel has 7 themes which can be selected via the 'Theme' illuminated push button or an external switch plugged into the 'Theme' input jack: 1 Piano 2 Various Instruments 3 Space 4 Carnival 5 Animals 6 Music 7 Guitar

Rompa® Wireless Operation

The Hip Hop Activity Box™ is compatible with a range of Rompa® wireless products (see Compatible Rompa® Products).

The panel has two unique modes of operation with wireless products which are Colour Mode and Game Mode. The panel will always start in Colour Mode and Game Mode can only be selected using either an 8 Colour Wireless Controller Simple (21006) or Deluxe (19847) by selecting the central 'Function Button':

Colour Mode

8 Colour Wirefree Controller: Simple and Deluxe

Pressing the colour buttons turns the all the panel the corresponding colour selected. The panel will remain this colour unless a new colour is selected via the panel or a Rompa® wireless controller or the panel will return to its normal operation by using the floor pad or timing out after 60 seconds.

Pressing the central 'function button' will switch the panel to the Game Mode.

Game Mode

It is recommended that only an 8 colour controller is used with game mode as the 8 colours on the controller match the 8 colours on the floor pad.

Pressing the central 'function button' will switch the panel to the Game Mode.

8 Colour Wirefree Controller: Simple and Deluxe

Pressing the colour buttons acts as pressing the corresponding colour on the floor pad. This means games and songs can be played via the wireless controller instead of the floor pad. The panel works as normal in this mode.



Pressing the central 'function button' acts will switch the panel back to Colour Mode.

Other Wireless Products

Selecting a colour acts as pressing the corresponding colour on the floor pad. This means games and songs can be played via the wireless controller instead of the floor pad. The panel works as normal in this mode.

The panel will ignore any colour which is not present on the floor pad e.g. shades of green which are not same as the green on the floor pad or 8 colour controllers will be ignored.


Some games require the user to be able to select all 8 colours of the floor pad or 8 colour controller. This means some wireless controllers will be poorly suited to Game Mode e.g. Talking Cube (18870) you can only select 6 colours.



FEATURES

07.

Panel Overview (Front)



NOTES

08.

snoezelen[®]



Life Changing Sensory Solutions For All

Rompa[®] Limited
Unit 1-4 Carrwood Industrial Estate,
Carrwood Road, Chesterfield, S41 9QB

customer.service@rompa.com

www.rompa.com