



BASKETBALL SET 16244

CONTENTS

Your Basketball Set arrives in one box containing:

Ball (supplied deflated)

Pump

Basket – ring with net and three detachable legs

BEFORE USE

1. Place the legs inside the leg supports of the basket ring. Make sure that the net is evenly distributed around the ring.
2. Inflate the ball using the pump supplied.
Please note: the 'needle' of the pump can be found inside the handle end of the pump (furthest away from the end where the needle is attached). Flip open the small lid in the handle end, take out the needle and screw the needle into the other end of the pump. Inflate the ball to the required size by putting the needle in the ball then pushing the handle end of the pump in and out, this may take a while but please be delicate with it!
3. Once the ball is inflated, put the needle back inside the handle and store the pump in a safe place should you wish to top the ball up at a later stage.

SAFETY

The Basketball Set has a longer net for safety reasons, in that once the ball is in the net, it cannot roll away – a useful aid for players in wheelchairs. Should you wish, the net can be shortened to allow the ball to roll free of the basket by tying knots in the top of the net, where it is joined to the rim.

As with all ROMPA® products, we recommend the supervision of this product.



CONJUNTO DE BASQUETEBOL 16244

CONTEÚDO

O seu conjunto de basquetebol é fornecido numa caixa que contém:

Bola (fornecida vazia)

Bomba

Cesto – anel com rede e três pernas destacáveis

ANTES DE UTILIZAR

1. Enfie as pernas dentro dos respectivos suportes do cesto. A rede deve estar distribuída uniformemente à volta do anel.
2. Encha a bomba utilizando a bomba fornecida.
Nota: A 'agulha' da bomba encontra-se na ponta da pega da bomba (na ponta mais longe do local onde a agulha é encaixada). Abra a pequena tampa na pega, retire a agulha e aperte-a na outra ponta da bomba. Encha a bola até ao tamanho necessário. Isto pode demorar um bocado, por favor seja paciente!
3. Quando a bola estiver cheia, guarde a agulha dentro da pega e coloque a bomba num local seguro para poder encher a bola novamente mais tarde.

SEGURANÇA

O conjunto de basquetebol tem uma rede mais comprida por razões de segurança, uma vez que a bola entre dentro do cesto, não pode rolar para fora – uma útil ajuda para quem utiliza cadeiras de rodas. Se desejar, a rede pode ser encurtada atando os nós mais acima para permitir que a bola role livremente do cesto.

Como em todos os produtos Rompa, recomendamos a supervisão deste produto.